



Please note: When end stops are used, the carriages must be indented by at least 1-3/16" [30 mm]. A flush installation of the carriages as per step 5 of the mounting instructions is therefore no longer possible. When end stops are used in combination with a damping mechanism on both sides, the door width increases by 2-3/8" [60 mm] respectively.

 Bohle America Inc 10924 Granite Street, Suite 200 Charlotte, NC 28273	 T +1 888 838 6006 F +1 704 547 8420 info@bohle-america.com	Description: MasterTrack Tt End Stoppers	
		Article(s): B05700009	
		Drawn by: AP	Date: 06.26.23